
Test / Usage

1 Test

- * Turn handle to "OFF" position. Open Water supply valve to check all connections for leakage;
- * Turn handle to "ON" position. Check the water flow.

2 Usage




Trouble Shooting Guide

Trouble	Checkpoint	Contents	Action
Poor flow rate	Aerator	Check any impurities.	Remove all impurities.
	Water supply valve	Check water supply valve open position.	Open it to full water supply valve
	Flexible hose	Check if flexible hose is twisted.	Untwist the flexible hose.
Leakage	Cartridge	Check cartridge packing.	When packing is damaged, replace the cartridge.
	Flexible hose connection	Check if the packing is losed. Check if the connection become loosen	Check the existence of packing and fix it again

Care & Maintenance

* If you want to do the maintenance for the faucet, please follow the below process.



- 4 -




Attention:
Please Leave the manual with the customer after installation is finished.

Milano

FFAS0901–102500BF0 Milano Basin Mixer

FFAS0902–102500BF0 Milano Extended Basin Mixer





To ensure that your installation proceeds smoothly--please

read these instructions carefully before you begin.

- * Ideal Standard always keep raising and improving the product design and performance, and reserve the right to modify
- the dimension and spefication. At this case, we will not inform you separately.
- * This installation instruction sheet is for your reference only, the dimension and specification is subject to the actual products.


Pre-Installation Checks


- * All instruction procedures must comply in strict accordance with applicable local plumbing and building codes
- * Remove all impurity in pipes before beginning to avoid clogging. Connect faucet pipes correctly.
- * Check installation the Dimension Drawing to ensure to install it correctly.

Conditions for use

- * Recommended water pressure: 0.1~0.5Mpa.
- * Environment Temperature:1~55°C
- * Steam is not allowed.

During installation of the faucet, Please grab the body. Do not grab handle only.





Rev. FF1-CN521K00158599/A2 - 1 -

